

产品使用说明书

OPERATION MANUAL

节能绷缝机

POWER SAVING INTERLOCK MACHINE

△ 安全须知

对于缝纫机本身各种装置，我们充分考虑到它的安全性。请遵照基本的操作方法，安全的进行工作。

●拆除为保证安全所设置的装置，零件的情况下使用，是非常危险的，请绝对不要拆除后使用。

●缝纫机在使用时，请不要在缝纫机台板上放置工具及缝纫时不必要的物品。

●在对缝纫机进行检查、修理、清扫等维护作业时，请关掉电源开关，将电源插销从插座上拔下，并确认缝纫机插板也不会转动后，再进行操作。

△ OBSERVE THESE SAFETY PRECAUTIONS

Though we takes the utmost care to produce safe sewing machines and devices, operators should follow these basic safety rules.

●To prevent accidents, do not remove safety devices or parts while operating the machine.

●Do not leave tools or other unnecessary objects on the machine table while operating the machine.


●Always turn off the power, unplug the machine and then make sure that the machine does not run by pressing the pedal before performing any maintenance, such as checking, repairing, cleaning, etc.

注意

使用离合式马达的情况下，在关掉电源①后因惯性作用会继续旋转。这时如不注意踩动缝纫机踏板②时，缝纫机会突然动作，这是很危险的。请在关掉电源后，仍继续踩动踏板②，直至缝纫机完全停下来为止。

Caution

A clutch motor keeps on running for a while by inertia after turning off the power① suddenly. If the machine pedal② is stepped on inadvertently, it is dangerous as the machine will start running unexpectedly. Keeping on stepping on the pedal② until the machine comes to a stop after turning off power suddenly.



- 在离开缝纫机台时，务必请关掉电源。
- 停电时也请务必关掉电源。
- 为了最安全地，运转良好的使用缝纫机，日常的点检是不可缺少的，请予以注意。
- Turn off the power before leaving the machine table.
- In the event of a power failure, be sure to turn off the power.
- Check that the machine is securely grounded.

缝纫机的清扫

缝纫机的清扫，以针板槽及送布牙周围为主。

Cleaning the machine


Mainly the slots of the needle plate and the feed rows should be cleaned.

压脚压力调节

压脚压力的调节是松开螺帽①和旋转螺丝②来进行的。在能取得平稳针脚的范围内，尽量调得松一些为好。

Adjusting the presser foot pressure


Loosen adjusting (1) nut and turn adjusting screw(2) to adjust the presser foot pressure. It should be as light as possible, yet be sufficient to obtain the proper stitch formation.



务必请在调节差动比之后进行。

Adjusting the stitch length

While pressing the push button,turn the handwheel to seek the position at which the push button goes further into the depth.Then keeping the button pressed,turn the handwheel and set the desired scale to the aligning mark. Note:Stitch length adjustment must only be made after the differential feed ratio has been changed.




台板加工图

Schematic diagram to the machine table

请参照下图进行台板的加工

Cut the referring diagram




差动比的调节

差动比是通过松开螺帽①后，把调节杆②上下移动来进行调节的。为了防止布纤维或线被切断，请尽早给HR装置供油。

注：硅油请使用本公司指定的冷却油。[请使用日本UNION CARBIDE(株)的UCC-L45(10)]

Adjusting the diff. feed ratio

Loosen nut(1) and move the lever up(2) and down to obtain the correct differential feed ratio then tighten nut(1).




线状态的调节

线状态的调节是用针线状态螺帽①，上装饰线状态螺帽②，下针状态螺帽③来进行调节的。

Thread tension


Mark tension adjustments with the needle thread knob(1),top cover thread knob(2) and looper thread knob(3).



手动给油 Manual lubrication

手动给油是在缝纫机最初开始使用时，或相当一段时间重新开始使用时，请供给2~3滴油。

机油请使用本公司指定的[HIGH SPEED SEWING MACHINE OIL](ISO粘度与VG22相同)。



●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●

●